

Fundamental Reactivity Testing and Analysis of Hydrogen Storage Materials & Systems



D.L. Anton, K.S. Brinkman, J. Gray, B. Hardy
Savannah River National Laboratory

Project ID #: ST 40

Timeline

- Start: 10/1/05
- End: 9/30/10
- Percent complete: 30%

Budget

- Proposed Budget: \$2M
- Funding received in FY07
 - \$300K
- Funding for FY08
 - \$500K

Barriers Addressed

- D. Durability/Operability
- A. System Weight and Volume
- Q. Reproducibility of Performance
- F. Codes and Standards

Partners

- M. Fichtner, Forschungszentrum Karlsruhe, Germany
- N. Kuriyama, National Institute for Advanced Industrial Science and Technology, Japan
- R. Chahine, Université du Québec à Trois-Rivières, Canada
- D. Mosher, United Tech. Res. Ctr., USA
- D. Dedrick, Sandia NL, USA

DoE On-Board Hydrogen Storage Technical Targets

Target	2007	2010	2015
Wt % H ₂ (Useable)	4.5	6	9
Vol. Cap. (kg H ₂ /L)	0.036	0.045	.081
Cycles	500	1000	1500
Minimum rate (g/s)/kW	.02	.02	.02
Minimum/Maximum pressure (atm) [FC]	8/100	4/100	3/100
Minimum/Maximum ambient temperature (°C)	-20/50	-30/50	-40/60
Start time to full flow (s)	4	4	0.5
System fill time (min)	10	3	2.5
Safety	Meet or exceed applicable standards		

Task Plan

- ***Task 1: Risk Assessment***
 - Assess the potential risks of using solid state hydrides
 - **Develop test protocols and experimental designs to aid in characterization of hypothetical accident scenarios**
 - Test six compounds in three discharge states using standardized semi-quantitative test methods
- ***Task 2: Thermodynamics & Chemical Kinetics***
 - Quantitatively assess chemical reactions of compounds with air, water & other engineering materials
- ***Task 3: Risk Mitigation***
 - Quantitatively assess chemical reactions of compounds with potential inhibitors
 - Evaluate efficacy of inhibitors in laboratory scale tests
- ***Task 4: Prototype System Testing***
 - Design assemble and test prototype storage systems to evaluate effectiveness of inhibitor systems.

Materials Test Plan

- All three major classes of condensed hydrogen storage materials are being studied: metal hydrides, chemical hydrides & adsorption hydrides.
- Priority of analysis is being conducted in consultation with the three Materials CoE's and DoE.

Little Known

Investigations Initiated

1. $2\text{LiBH}_4 + \text{MgH}_2$
2. NH_3BH_3
3. Activated Carbon
4. AlH_3

Some Known Complete Analysis

- $\text{NaAlH}_4 + 2\%\text{TiCl}_3$
- $2\text{LiH} + \text{Mg}(\text{NH}_2)_2$
- Mg_2NiH_4
- LaNi_5H_6

Materials Prep Plan

- Use Particle Size
 - Fully Charged
 - Partially Discharged
 - Fully Discharged

Background: $2\text{LiBH}_4 + \text{MgH}_2$




J. Vajo, J. P. Chem. B Letters, Vol 109, pg 3719 (2005).


wt% = 11.4%

$\Delta H = 40.5 \text{ kJ/mole H}_2$



discharge



Recharge: 100 bar



Apparatus for Pyrophoricity Test



**Video Recording
Device and / or IR
Camera**

1. Drop a small amount (< 1 g) of material in a containment box under ambient conditions
2. Observe material as it falls and for a period of < 5 min. after falling.
3. Check for:
 1. Gas evolution
 2. Spontaneous ignition
4. Video record experiment

$2\text{LiBH}_4 + \text{MgH}_2$ Pyrophoricity Test




Materials do not undergo reaction in air



time



Hygroscopic material absorbs H_2O from air



No reaction in 15 minutes (5 minutes for standard test)


time

Instrumented Apparatus for Self-Heating




(25 mm)³ wire mesh
sample basket

- Fill the 25mm³ sample holder with material
- Sample holder pre-fitted with micro thermocouples
- Heat sample to 150°C
- Observe temperature within sample spatially resolved to determine if self-heating occurs




$2\text{LiBH}_4 + \text{MgH}_2$ Self-Heating

- Sample begins to self-heat within 30 seconds of exposure in the oven
- Maximum Temperature observed = 447°C



- Reaction initiates at sample surfaces and propagates towards the interior
- Consistent with diffusion of air/water vapor into the packed powder sample

Apparatus for Burn Rate Test



1. Pack a triangular prism mold 20mm x 10mm x 250mm with material
2. Place material on fire resistant base, with thermocouples fitted underneath at 35mm intervals
3. Introduce flame at one end of packed material
4. Observe whether flame propagation occurs
 1. Measure rate of propagation
 2. Monitor linear temperature distribution



Video Recording
Camera

$2\text{LiBH}_4 + \text{MgH}_2$ Burn Rate



Flame rapidly moves to right and
continues to burn for several minutes

$2\text{LiBH}_4 \cdot \text{MgH}_2$ Burn Rate Measurement




- Burn rate
= 52 mm/sec
- Burn rate for NaAlH_4
= 51 mm/sec¹

- Variations in max temperature attributed to variations in packing density.
- Burn rate is very similar to NaAlH_4


Experimental Setup of Water Contact Tests

Water Immersion




1. Drop ~ 20 mg of material into excess of H_2O (250 ml)
2. Check for:
 - a) Gas evolution
 - b) Spontaneous ignition
3. Video record experiment

Surface Contact



1. Drop ~ 20 mg of material onto filter paper on the surface of an excess of H_2O (250 ml)
2. Check for:
 - a) Gas evolution
 - b) Spontaneous ignition
3. Video record experiment

Water Drop



1. Contact a small pile (~ 2 g) of material with a few drops of H_2O
2. Check for:
 1. Gas evolution
 2. Spontaneous ignition
3. Video record experiment

$2\text{LiBH}_4 \cdot \text{MgH}_2$ Water Immersion

t=0 sec



T = 2 sec



time


H_2 bubble
evolution

t=2 min



Coalescence
and sinking of
products

t=7 min




time

$2\text{LiBH}_4 \cdot \text{MgH}_2$ Surface Contact



H₂ bubble evolution



time

Conflagration of hydrides and hydrogen gas



t=5 min



time

$2\text{LiBH}_4 \cdot \text{MgH}_2$ Water Drop

t=0 sec

Two drops
of H_2O



t=2 sec



t=3 sec



Conflagration of hydrides
and hydrogen gas

time

t=3 min

Material burns for
several minutes



t=5 min



t=8 min



time



MgH_2 -Hydrophobic - LiBH_4 -Hydrophilic
Material ignites when enough heat and hydrogen are generated

Standardized Tests for $2\text{LiBH}_4 \cdot \text{MgH}_2$

<u>UN Test</u>	<u>Result</u>	<u>Comments</u>
Pyrophoricity	Pass	No combustion event. Hygroscopic material absorbed H_2O from air.
Self-Heat	Fail	Self-heated $\sim 300^\circ\text{C}$ within 30 sec.
Burn Rate	Fail	Flame propagated at a burn rate of 52 mm/sec.
Water Drop	Fail	2 H_2O drops required for near-instant combustion.
Surface Contact	Fail	Restricted H_2O surface contact results in combustion
Water Immersion	Fail	No combustion event recorded. Gas evolved at longer times. (5 min)

- Material is classified as packing class 4.3 – Dangerous When Wet
- Same packing class as pure components


Thermodynamic Assessment of Environmental Exposure

- Thermodynamic analysis completed for all materials available in the data base

Gibbs Free energy of lowest energy reaction

ΔG (kJ/mol) at 373 K


per mol of total starting material




- Thermodynamics predict greatest energy release for oxygen reactions
- Generally, thermodynamic calculation did not predict experimentally observed products

Thermo-Chemical Analysis of Water Contact

Calorimetric Apparatus





Calorimetric signal from mixing ~ 10 mg $2\text{LiBH}_4 + \text{MgH}_2$ and 1ml water at 40°C and 70°C




- More complete reaction or additional reactions occurring at 70°C .
- Investigating NMR and Raman of products to elucidate reactions.

Kinetics of Water Contact: $2\text{LiBH}_4 + \text{MgH}_2$

Fully Charged



Different Products at Different Temperature





Different reaction products is further evidence of differences in reaction pathway previously identified

Thermo-Chemical Analysis of Humid Air Exposure

Calorimetric Apparatus

Conditioned
Temperature & Humidity
Gas Inlet



Gas
Outlet





sample

Reaction profile resembles multi-step reaction or surface spallation effect, not a single step reaction.

Gas Product Analysis



$2\text{LiBH}_4 + \text{MgH}_2$ calorimetry in air at 70°C and 30% RH





Heat flow signal during gas sampling (sample time ~ 1 min.) vs. H₂% determined via Gas Chromatography (GC)

- Hydrogen concentration in gas stream tracks heat flow signal
- Flammable concentrations of hydrogen observed

Gas versus Liquid Hydrolysis/Oxidation Comparison

Heat flow during hydrolysis with 40°C humid air
20% humidity and
40°C liquid water






Water quantity:

Liquid: $t=0$, mol actual/mol stoichiometric=32%


Gas: $t_{\text{stoichiometric}}=3.5$ hours $t=12$ hours, mol actual/mol stoichiometric=350%

- Liquid water hydrolysis displays maximum heat flow
- Oxygen in air is only a small contributor to heat flow signal


Reactivity Comparison



Discharged material state more reactive:
Charged



Discharged




Preliminary NH_3BH_3 Testing Initiated

■ 1) Calorimetry

Argon gas flow with 30% RH at 40°C

Small exothermic reaction
products under analysis



■ 2) UN test

— Water drop



t=0 s



No reaction
with
addition of
 H_2O drops

Predictive Models

- Preliminary experiments suggest:
 - Exposure of media to humid environment leads to:
 - Exothermic reaction and H₂ generation
 - Low thermal conductivity of media causes temperature to rise
 - H₂ at surface and in pores burns if & when auto ignition temperature of 571°C is reached
 - Burning of H₂ initiates pyrolysis of media
- Correlations will be developed, in terms of non-dimensional parameters, that:
 - Predict whether H₂ ignition occurs
 - Predict time to ignition
 - Predict whether pyrolysis occurs
- Correlations will be developed on salient material properties of media and dimensions of media pile

Task 2 Plans

- Summarize results of calorimetric tests and UN tests in a DOE report for the $\text{LiBH}_4 + \text{MgH}_2$ material system
- Continue liquid phase and gas phase calorimetry of NH_3BH_3
- Identify amorphous reaction products (Raman, NMR)
- Assess risks based on observed thermo-chemical release

Task 3 Plan

- **Identify risk mitigation strategies including contaminants and poisons which will reduce exothermic releases.**
- Evaluate theoretical thermodynamics of mitigation strategies for water and air exposures initially on NH_3BH_3 , $2\text{LiBH}_4+\text{MgH}_2$, $2\text{LiH}+\text{Mg}(\text{NH}_2)_2$, AlH_3 & NaAlH_4 .
- Perform calorimetric experiments of mitigation strategies for water exposure at $0<T<50^\circ\text{C}$.
- Perform calorimetric experiments of mitigation strategies for conditioned air exposure at $0<T<100^\circ\text{C}$, $0<\%RH<100\%$.
- Identify reaction products.
- Assess mitigation strategies effectiveness based on observed thermo-chemical release.

SRNL FYs '07 & '08 Work

- **Coordinate IPHE team to complete experimental analysis, compile results and disseminate findings and conclusions.**
- **Complete standardized tests UN hazards analysis tests on NH_3BH_3 , $2\text{LiH} + \text{Mg}(\text{NH}_2)_2$ & AlH_3 .**
- **Perform calorimetric experiments on environmental exposure reactions, assess reaction products and chemical kinetics as a function of T & %RH.**
- **Determine chemical reaction & thermal discharge rates to assess risks.**