

# High Throughput Combinatorial Chemistry Development of Complex Hydrides



Darshan Kundaliya, Jonathan Melman, Xiongfei Shen, Hyung-Chul Lee, Tom Enck and C. Bajorek

**Intematix Corporation**

*In Association with the DOE/Metal Hydride Center of Excellence*

**Project ID #STP17**



## Project Timeline

- Start date: March 2005
- End date: February 2008
- 100% Percent complete

## Budget

- Total project funding
  - ✓ DOE share: \$870K
  - ✓ Contractor share: \$218K
- Funding received in FY07: \$270K

## Partners

- HRL
- Sandia National Lab

## Barriers

- Slow kinetic reaction (E)
- Thermodynamic stability (J)
- Low reversible storage (P)
- In-situ thin film characterization (Q)

# Objective

## Overall

- Identify and synthesize novel metal hydride systems using high-throughput combinatorial technique
- Identify catalysts to achieve fast reaction kinetics for metal hydride systems and thus support DOE's 2010 targets for start time (4 s), flow rate (0.02 (g H<sub>2</sub>/s)/kW) and refill time (3 min)

## 2006

- Validate combinatorial nano-synthesis systems for catalyst discovery
- Screen and identify better catalysts for MgH<sub>2</sub> + Si system
- Screen and identify better catalysts for complex LiBH<sub>4</sub> + MgH<sub>2</sub> dehydrogenation and hydrogenation

## 2007

- Synthesize and characterize novel complex hydride materials in thin films format
- Continue catalyst screening on LiBH<sub>4</sub> + MgH<sub>2</sub> system based on leads obtained in 2006
- Support other MHCoe partners for thin film deposition

## 2008


- Validate Combinatorial Optical Screening technique for complex hydrides such as NaAlH<sub>4</sub> and LiBH<sub>4</sub>

# Accomplishments

- Validation of two combinatorial synthesis techniques
- Validation of three high throughput screening techniques
- ❑ Validation of Optical Screening for complex and simple hydrides
- Catalyst screened: ~100 metals and alloys
- Found better catalyst for  $\text{MgH}_2 + \text{Si}$  dehydrogenation
  - ❑ Did not identify any effective rehydrogenation catalyst
  - ❑ System down-selected due to lack of rehydrogenation at IMX or other Center Partners
- A few catalyst leads found for  $\text{LiH} + \text{MgB}_2$  system hydrogenation, however, this entry point into the system is not very promising
- Catalyst screening in progress for  $\text{LiBH}_4 + \text{MgH}_2$  dehydrogenation
- Proven successful synthesis of thin film materials on both known and novel complex hydride materials [e.g.  $\text{LiBH}_4$  and  $\text{Ca}(\text{BH}_4)_2$ ]
- Patents filed: 2
- Intematix accomplished validation of its tools for high-throughput combinatorial catalyst screening ahead of schedule

# The Partner Approach

Methodology used for metal hydride synthesis  
and combinatorial catalyst screening




# Intematix's Joint Development Program



Courtesy NREL


Thin Film Solar Cell & Down Conversion Technology




Fuel Cells, H<sub>2</sub> Generation and Storage




Security Phosphor Materials & System




Li Battery Materials



High-k Metal Gate



Non-Volatile Memory



Catalysts for Biofuels



LED, PDP, CCFL Phosphors

# Catalysts Screening for Metal Hydride



## **\*\*Methodology\*\***

- Combinatorial thin film deposition of catalyst library and in-situ annealing using Ion Beam Sputtering System (primary tool)
- Combinatorial growth of metal nanoparticles using Laser Pyrolysis
- Laser Annealing of metal library in hydrogen pressure cell (Near Future)

## **\*\*Techniques\*\***

- Real-Time monitoring of optical variations with temperature under different environments
- Optical reflectivity determination (Only for thin film samples)
- Ex-situ scanning X-ray diffraction



## **\*\*Confirmation\*\***

MHCoE partners collaboration (HRL, SNL)





# Ion Beam Sputtering: A Combinatorial Approach



**Advantages**

**Capabilities**

**Status**


**Ultra-fast combinatorial materials synthesis**

**Combinatorial synthesis of metal hydrides and/or catalysts thin films**

**Validated for metal hydride and catalyst synthesis**



# Experimental Details – Catalyst Screening



Methodology for catalyst screening validated by 'rediscovery' of known catalyst as well as discovery of a new, better catalyst.

# High Throughput Screening Tools-1

## Optical Screening

- 1) Using High Pressure Optical Chamber
- 2) Max. Pressure: 600 psi
- 3) Max. Temperature: 350 °C
- 4) Max. Sample Size: 3 x 3 cm



Mg thin film (250 nm)  
before  
hydrogenation



MgH<sub>2</sub> thin film  
after  
hydrogenation

### Methodology:

#### **At constant pressure:**

Change in optical properties versus temperature

#### **At constant temperature:**

Observe the of change in optical properties versus pressure

### Conclusion:

A change in color, as indicated by image processing, at a particular catalyst, indicates that a reaction may have taken place (lead generated for further catalysis study)


Change in optical property is a combination of change in reflectivity and the respective transmission stemming from change in underlying band structure.

Griessen & coworkers, Scripta Materialia 56, 853 (2007)


# Example Libraries




**Library 1**



**Library 2**



# NaAlH<sub>4</sub> Literature



Ti known to catalyze H<sub>2</sub> release from NaAlH<sub>4</sub>

Jensen & coworkers, J. Phys. Chem. B 107, 10176 (2003)

# Validation of Method with $\text{NaAlH}_4$



## Experimental Conditions


Gas Environment: Vacuum

Temperature: RT to 200 °C

Rate: 3 °C/min

Temp (°C)	25	50	75	100	125	150	175	185	185	200	200
									5 min		90 min

$\text{NaAlH}_4$   
As available



Temp (°C)	25	50	75	100	125	130	140	150	160	160 (30 mins)
-----------	----	----	----	-----	-----	-----	-----	-----	-----	---------------

No Ti




No change

100Å  
Ti film



$\text{H}_2$  release  
at 160 °C


5%  
 $\text{TiBr}_4^*$



$\text{H}_2$  release  
at 160 °C


$\text{NaAlH}_4$  deposited on the substrate as a  
slurry in hexane or anhydrous toluene

# Intematix Results: Image Processing and XRD



Ti identified as a catalyst for the system



XRD confirms phase change and hydrogen release:




Rehydrogenation attempted but unsuccessful as 500 psi H<sub>2</sub> is below the 1500 psi where facile reaction would be expected



# NaAlH<sub>4</sub> Literature Matches Experimental Results



Pure NaAlH<sub>4</sub> transforms to Na<sub>3</sub>AlH<sub>6</sub> ~190 °C




Ti catalyzed NaAlH<sub>4</sub> transforms ~150 °C

Singh et al., Acta Materialia **55**, 5549 (2007)

# Validation

- Methodology validated on  $\text{NaAlH}_4$  system; results both with and without Ti match expected behavior
- Observation of catalysis in “bulk-like” sample
- Observation of catalysis by thin film deposited catalyst sample on a complex hydride
- XRD can be used as direct confirmation of product formation
- These results enable us to trust both the thin film catalyst deposition approach and the sample preparation methodology

# Dehydrogenation – Catalyst Screening for $\text{MgH}_2 + \frac{1}{2} \text{Si}$ Powder




Optical Properties Screening (heated at 3 °C/min):

(°C)	25	140	180	190	210	260	300	320	350	
Ni										H <sub>2</sub> release at 260 °C
Mn										H <sub>2</sub> release at 210 °C
Cu										No change observed
Fe										No change observed

- ❑ Catalytic effect observed with thin film metal deposited on covalent metal hydride
- ❑ Ni known by HRL, Mn previously unknown
- ❑ Non-reaction with Cu and Fe thin films confirms catalytic versus morphological nature of thin film Mn and Ni
- ❑ We have confirmed that there is no change in the optical properties of pure material under the similar conditions (1 bar Ar, time= 2 hrs, max T = 350 °C)

Catalysts screened: Ni, Mn, Cr, Fe, Ti, Nb, Pt, V, Cu,  
and  
40 binary alloys


# Image Processing of $\text{MgH}_2$ + Si optical screening



- Blanks show effect of heating catalyst in presence of argon
- No difference between blank and experiment for Ni or Mn
- Image processing quantitatively shows transition temperatures, which are key to interpreting results

# Hydrogen Desorption Catalyst Confirmation from Center Partner





## MgH<sub>2</sub>/Si + Catalyst



- A similar approach was used by HRL: heating at 2 °C/min
- Pure MgH<sub>2</sub> + Si takes 7.5 hr for onset of decomposition (shown by vertical dashed line)

**Nano-Mn, Ni and Ni-Co give similar enhancements for dehydrogenation**

# Micro-beam scanning XRD results



**Limitation:** *Not configured for highly air sensitive materials*





# Hydrogenation – Catalyst Screening for $\text{LiH} + \text{MgB}_2$

Temp (°C) → RT 100 200 250 300 325 350 350 (1 Hr)

Nb

CrMn



- Evidence for Nb metal, CrMn alloy catalysis
- Screened ~50 catalysts combinations of Fe, Ni, Nb, Pt, Ru, Cr, Mn, Mg, V
- More careful analysis is required
- Most promising results shown here
- Further validation necessary

Also, screened 25 catalyst for  
Dehydrogenation of  $\text{LiBH}_4 + \text{MgH}_2$

# Thin film systems




# Combinatorial Thin Film Design Approach




## Rationale:


- 1) Addresses/solves non-uniformity of powdered (ball-milled) sample
- 2) Opportunity to explore novel nano-material system in a “**controlled**” fashion.
- 3) Catalysts can be sandwiched between the complex hydride layers increasing effective loading
- 4) More accurate data accumulation using automated optical reflectivity setup for hydrogenated and dehydrogenated samples.
- 5) Role of morphology, microstructure and stress on hydrogen storage can be studied effectively
- 6) Sensitive elements, such as Li, can be deposited very efficiently and effectively.
- 7) Sample size can be varied depending on the experiments



Multilayer Approach




Multilayer + Discrete library




Ternary Continuous library


# Li-B-Mg-Ti Thin Film, 350 °C and 500 psi H<sub>2</sub>



(Li=10 Å, B=10 Å) x 5 =100 Å; (Ti=10Å, Mg=10Å) x 1;




False color reflectivity mapping indicates hydrogen uptake (darkening from right to left); confirmed by Raman





Mg & Ti were added as catalysts based on LiBH<sub>4</sub> bulk systems in the literature

Vajo et al., J. Phys. Chem. B **109**, 3719 (2005)  
Yu et al., Chem. Comm. 3906 (2006)  
Au et al., J. Phys. Chem. B **110**, 26482 (2006)

# Ca-B Mixture Thin Film With Catalyst Library



Hydrogenation temperature=440 °C  
Hydrogen pressure=15,000 psi



Optical reflectivity and an image of Ca, B mixture with discrete catalyst libraries.

Indication of B-H bond formation, but not necessarily  $\text{BH}_4^-$ , possibly a higher order  $\text{B}_x\text{H}_y^{n-}$ , based on the Raman spectra. Such a compound is likely an intermediate in the formation of  $\text{BH}_4^-$  from elemental B and  $\text{H}_2$ .




# Complementary Synthesis Technique – Combinatorial Nano-particle (CNP) System





## Capabilities:

- ❑ Synthesis of nanoparticles of metals, oxides, hydrides, nitrides, carbides, sulfides, etc.
- ❑ Reproducible high crystalline quality nanoparticles with narrow size distribution ( $< \pm 30\%$ )
- ❑ Synthesis of combinatorial nano-particle libraries with controllable parameters:
  - particle size
  - material composition
  - synthesis conditions
- ❑ System has been validated for bimetal alloy libraries



Typical  
Example



For example, this system has generated Ni particles for Mg<sub>2</sub>Si



# Summary



## **Goal:**

Identify catalysts which improve the kinetics and selectivity for desired metal hydride systems to enable an on-board hydrogen storage system which meets DOE 2010 targets.

## **Approach:**

Combinatorial nano-catalyst synthesis and high throughput screening to speed up catalyst discovery.

## **Technical Accomplishment and Results:**

- (1) Improvement in design, setup and validation of combinatorial nano-catalyst synthesis and high throughput catalyst screening processes.
- (2) Validation of Optical Screening for complex and simple hydrides
- (3) Proven successful synthesis of thin film materials on both known and novel complex hydride materials [e.g.  $\text{LiBH}_4$  and  $\text{Ca}(\text{BH}_4)_2$ ]
- (4) Ni and Mn were found to be the most effective catalyst for  $\text{MgH}_2 + \text{Si}$  system for dehydrogenation. But, NO Reversibility. So, NO-GO system.
- (5) Identified a few alloy leads which appear to improve kinetics of  $\text{LiH} + \text{MgB}_2$  system. But more catalyst screening is necessary for further improvement.

## **Proposed Future Research:**

Project Complete